



# Quick Installation Guide Reference

## ComfoAir 350 L Luxe

comfosystems



Duct Configuration	Mounting Options	Other
 <p>ComfoAir 350 - LEFT</p>	 <p><i>The place of installation must be chosen so that there is sufficient room around the unit for air duct connections, intake and exhaust piping and in order to carry out maintenance work including replacement of filters.</i></p>	<p>Weight – 39Kg</p> <p>Condensate Drain – 32mm</p> <p>Spigot size – 160mm</p> <p>Voltage – 230 V~, 50 Hz</p> <p>Luxe Cable – 4 x 0.25mm<sup>2</sup> protected (twisted pair)</p>

# Quick Installation Guide Reference

## ComfoAir 350 L Luxe

comfosystems



### Wiring

External Wiring for CA350LUXE using CCLuxe LCD Interface  
(Shown with multiple optional wireless 'RF' slave switches)

